

Fenstertasche

für Citroën Spacetourer/Peugeot Traveller/Opel Zafira Life/
Toyota ProAce Verso (L2)

919175 / 919176

MONTAGEANLEITUNG

SCHRITT 1

①



Ziehen Sie das selbstklebende Flauschband von der Klettverbindung am Taschenboden ab und kleben Sie es in die Fensterbrüstung. Reinigen Sie die Klebefläche vorher sorgfältig. (Foto ①)



SCHRITT 2

②



③



Schieben Sie die Fenstertasche zwischen Scheibe und die hintere Gurtführung (Foto ②) und achten Sie darauf, das sich dabei die Lasche oben (rot markiert) hinter den Innenhimmel-Rand am oberen Scheibenrand schiebt. (Foto ③)

SCHRITT 3

④



Binden Sie vorn die 2 Bänder hinter dem Gurtumlenkpunkt zusammen. (Foto ④)

Bitte beachten Sie die maximale Traglast von 5 kg.

Window bag

for Citroën Spacetourer/Peugeot Traveller/Opel Zafira Life/
Toyota ProAce Verso (L2)

919175 / 919176

ASSEMBLY INSTRUCTIONS

STEP 1

①



Peel off the self-adhesive fleece tape from the Velcro connection at the bottom of the pocket and stick it into the window sill. Clean the adhesive surface carefully beforehand. (Photo ①)



STEP 2

②



③



Slide the window pocket between the window and the rear belt guide (photo ②), making sure that the tab at the top (marked in red) slides behind the edge of the headliner at the top of the window. (Photo ③)

STEP 3

④



Tie the 2 straps together at the front behind the belt deflection point. (Photo ④)

Please note the maximum load of 5 kg.